



PBR TRS-BT

46-Point Gold-Plated TRS Patchbay plus BT

CONNECTING WIRELESS BT


Once you have installed your PBR TRS-BT where you need it, plug it in to an appropriate power source. **Note: The power supply is only needed for Bluetooth audio.**

Plug in your equipment to the correct outlets on the PBR TRS-BT.

Once the power supply is plugged into the power inlet, the PBR TRS-BT BT is active. To sync your device to the PBR TRS-BT, press and hold the BT Sync button. Once the BT Status LED has started to blink, devices are able to find the PBR TRS-BT via BT connection.

To sync another device to the PBR TRS-BT, press and hold the Bluetooth Sync button.

1. **Power Inlet:** Connect power supply here. Power is only necessary for Bluetooth connection.
2. **BT Sync:** This button operates the BT Sync. Press and hold this button to set the PBR TRS-BT to "sync mode", when connecting new devices.
3. **BT Status:** When this LED is blinking, the PBR TRS-BT is ready to be paired. When this LED is lit, the PBR TRS-BT is synced to a device.
4. **BT Left Output:** This TRS jack outputs the left channel of the Bluetooth audio.
5. **BT Right Output:** This TRS jack outputs the right channel of the Bluetooth audio.



On phantom power

We advise against running phantom power through your patchbay, as this makes it possible to send phantom power to a device not designed to handle it; expensive damage could result!

If you decide to route phantom power through your patchbay, **always** ensure that your phantom power source is turned off before changing any connections.

Failure to do so can cause unbalanced shorts when a plug is inserted or removed, damaging input transistors of hardware processors, or damaging the transformer or ribbon of a ribbon mic.

IMPORTANT SAFETY INSTRUCTIONS



1. Read these instructions.
2. Keep these instructions
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with dry cloth.
7. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding-type plug has two blades and a third grounding prong. The wide blade or third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus. If the power cord becomes frayed, stop using immediately.
11. Use only attachments/accessories specified by the manufacturer
12. Use only with a cart, stand, tripod, bracket or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
13. Unplug this apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
15. This apparatus shall not be exposed to dripping or splashing, and no object filled with liquids, such as vases, shall be placed on the apparatus.
16. The mains plug or power inlet on the product is used as the disconnect device, so the disconnected device shall remain readily operable when reconnected.
17. Any changes or modifications not expressly approved in this manual could void your authority to operate this apparatus.

IMPORTANT!

The lightning flash with an arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.



This product complies with all international standards for safety and emissions including IEC62368 and FCC Part 15-B.

Do not attempt to service this unit yourself, as it will void your warranty. Please check your unit carefully upon receipt and return to place of purchase immediately if there are any problems with the product. After that, the standard Black Lion Audio 3 YEAR warranty will apply to defects in materials and workmanship.

U.S.A.

Should your Black Lion Audio product require service, please contact us on our customer service site: <https://www.blacklionaudio.com/contact>. **You must obtain an RA # (Return Authorization number) from us before shipping a unit back to us. This RA # must be clearly written on the outside of the box.**

Please safely pack the units...It is best to use the original packing materials. Black Lion Audio cannot be responsible for any damages incurred in shipping to us due to poor packaging. PLEASE PACK CAREFULLY and FULLY INSURE THE SHIPMENT.

INTERNATIONAL

For service or warranty assistance, please contact the Black Lion Audio distributor in your country through the dealer from whom you purchased this product.

LIMITED 3 YEAR WARRANTY

Black Lion Audio's PBR TRS-BT is warranted by Black Lion Audio to be free from defects in materials and workmanship for the period of THREE (3) YEARS to the original purchaser. In the event of such defects, the product will be repaired without charge or, at our option, replaced with a new one if delivered to Black Lion Audio prepaid, together with a copy of the sales slip or other proof of purchase date. The warranty excludes problems due to normal wear, abuse, shipping damage or failure to use the product in accordance with the specifications.

All parts and labor are covered under this Limited Warranty. However, if it is determined by Black Lion Audio that the device was damaged or made defective through abuse, we reserve the right to charge the customer for the cost of the repair.

Black Lion Audio shall not be liable for damages based upon inconvenience, loss of use of the product, loss of time, interrupted operation or commercial loss or any other damages, whether incidental, consequential or otherwise. This warranty gives you specific legal rights, and you may have other rights, which will vary from state to state.

This warranty is not transferable.

RAD Distribution
180 Carpenter Ave.
Middletown, New York, 10940
USA

Revised 07-31-24